



Sharp Aquos LC13B2UA LCD Replacement

Written By: Robert Hobson





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Remove the four 8mm screws attaching the stand to the TV.

Step 2




- Lift the stand off the television.

Step 3 — Back Case



- Remove the two back panels to display the audio and video inputs..

Step 4






- Remove the eight 6mm Phillips screws around the edge.
- Remove the two 6mm Phillips near the inputs.

Step 5



- Lift and remove the back case of the television.



Step 6 — Motherboard



- Remove the two speaker cables and the connector from the circuit board by pinching the plastic connectors and firmly pulling up.



⚠ Pull on the plastic part of the connector, even though it may seem easiest to pull on the wires.

Step 7




- Remove the green and gray power connector from the side of the buttons panel at the top of the television.
- Remove the green/gray to orange/gray connector from the center of the circuit board.

Step 8




- Remove the four 5mm Phillips screws attaching the LCD and circuit board to the front case.

Step 9




- Lift the circuit board/LCD block from the case by lifting the near side of the circuit board and sliding it under the button frame.

Step 10 — LCD




- Flip the LCD/circuit board so that the circuit board faces up.

Step 11




- Remove the three 5mm Philips screws attaching the circuit board to the LCD.
- Remove the five 6mm Phillips screws from the edges of the circuit board attaching it to the LCD.

Step 12




- Turn the circuit board so the blue and pink side cables are facing you.
- ⓘ Hold the white plastic, squeeze and pull from the sides.
- ⚠ Pull on the plastic part of the connector, even though it may seem easiest to pull on the wires.

Step 13




- Turn the television so the right hand side is facing you.
- ⓘ To remove the ribbon cables, fold the brown casing down and pull directly upward on the ribbon.
- Turn the television so the left hand side is facing you, and remove the ribbon cable in the same manner.

Step 14



- Turn the circuit board so that the left side is facing you.
- Detach the data cable from the circuit board.
- To do this, slide your finger nail from the middle of the connector until the little black tabs rotates down toward the board as shown in the second picture.

Step 15



- Lift and remove the circuit board from the LCD frame.

Step 16



- Now you have your LCD.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 02:26:05 PM.